BioResearch

Lonza

Amaxa™ HT Nucleofector™ protocol for MCF7 (ATCC®)

Cell description

Human mammary gland adenocarcinoma; adherent epithelial cell line (ATCC® HTB-22™, cryopreserved).

Example for Nucleofection™ of MCF7 (ATCC® HTB-22™)



Transfection efficiency and viability of MCF7 cells 24 hours post Nucleofection™. MCF7 cells (ATCC® HTB-22™) were transfected with program EN-130-AA and 0.4 µg of pmaxGFP™ vector. 24 hours post Nucleofection™ cells were analyzed on a FACSCalibur™ with HTS option (Becton Dickinson). Cell viability was determined as % PI negative cells.

Product description

Recommended kits

SE cell line HT Nucleofector™ kit

Cat. No.	V5SC-1002
Size (reactions)	2×384
SE cell line HT Nucleofector™ solution	22.5 ml
Supplement	5 ml
pmaxGFP™ vector (1 µg/µl in 10 mM Tris pH 8.0)	50 µg
384-well Nucleocuvette™ plate(s)	2

Cat. No.	V5SC-1010
Size (reactions)	10×384
SE cell line HT Nucleofector™ solution	90 ml
Supplement	20 ml
pmaxGFP™ vector (1 µg/µl in 10 mM Tris pH 8.0)	150 µg
384-well Nucleocuvette™ plate(s)	10

Storage and stability

Store Nucleofector™ solution, supplement and pmaxGFP™ vector at 4°C. For long term storage pmaxGFP™ vector is ideally stored at -20°C. The expiry date is printed on the solution box. Once the Nucleofector™ supplement is added to the Nucleofector™ solution it is stable for three months at 4°C.

Note

HT Nucleofector™ solutions can only be used with conductive polymer cuvettes, i.e. in the HT Nucleofector™, the 96-well Shuttle™ device and in the 4D-Nucleofector™ system. They are not compatible with the Nucleofector™ II/2b device.

Required material

Note
Please make sure that the entire supplement is added to the Nucleofector™ solution.

- HT Nucleofector™ System
- Supplemented HT Nucleofector™ solution at room temperature
- Supplied 384-well Nucleocuvette™ plates
- Supplied pmaxGFP™ vector, stock solution 1 µg/µl

Note
Volume of substrate solution added to each sample should not exceed 10 % of the total reaction volume (2 µl for 20 µl reactions). For positive control using pmaxGFP™ vector, please dilute the stock solution to reach the appropriate working concentration.

- Substrate of interest, highly purified, preferably by using endotoxin free kits; A260 : A280 ratio should be at least 1.8
- 384-well Nucleocuvette™ plates are best handled with an automated liquid handling system. If manual pipetting is required please use compatible tips: epT.I.P.S.™ (US/CDN: Eppendorf North America, Cat. No. 2491.431, Rest of World: Eppendorf AG, Cat. No. 0030073.266), Matrix TallTips™ (Matrix Technologies Corp., Cat. No. 7281) or LTS Tips (Rainin Instrument, LLC, Cat. No. SR-L10F, SR/SS-L250S, SR/SS-L300S). Before using other types of pipette tips, please ensure they reach the bottom of the Nucleocuvette™ wells without getting stuck
- For detaching cells: 0.05 % trypsin/0.02 % EDTA and supplemented culture media or PBS/0.5 % BSA
- 96-well culture plates or culture plates of your choice
- Culture medium: Minimum essential media (Eagle) with 2 mM L-glutamine and Earle's BSS adjusted to contain 1.5 g/L sodium bicarbonate, 0.1 mM non-essential amino acids and 1 mM sodium pyruvate, 90 % (ATCC®, Cat. No. 30-2003) supplemented with 0.01 mg/ml bovine insulin (Sigma, Cat. No. I-0516); fetal bovine serum (ATCC®, Cat. No. 30-2020)
- Prewarm appropriate volume of culture media at 37°C (225 µl per sample)
- Appropriate number of cells (4×10^5 cells per sample; lower or higher cell numbers may influence transfection results)

1. Pre Nucleofection™

Cell culture recommendations

1.1 Replace media 2–3 times week (30 ml per 162 cm^2 flask) cells should be passaged at 75–80 % confluency
1.2 Seed out 2×10^5 cells/cm^2
1.3 Subculture 3–4 days before Nucleofection™
1.4 For Nucleofection™ cells should be 75–80 % confluent

Trypsinization

1.5 Remove media from the cultured cells and wash cells once with PBS; use at least same volume of PBS as culture media
1.6 For harvesting, incubate the cells at 37°C with e.g. 0.05 % trypsin/0.02 % EDTA
1.7 Inactivate trypsinization reaction with supplemented culture media or PBS/0.5 % BSA

2. Nucleofection™

One Nucleofection™ sample contains

- 4×10^5 cells
- 0.2–1 µg plasmid DNA (in 1–2 µl H_2O or TE) or 0.4 µg pmaxGFP™ vector or 30–300 nM siRNA (0.6–6 pmol/sample)
- 20 µl SE cell line HT Nucleofector™ solution

2.1 Please make sure that the entire supplement is added to the Nucleofector™ solution

2.2 Start HT Nucleofector™ software, verify device connection and upload experimental parameter file (for details refer to the HT Nucleofector™ manuals)

2.3 Select the appropriate HT Nucleofector™ program **EN-130-AA**

2.4 Prepare cell culture plates by filling appropriate number of wells with desired volume of recommended culture media, e.g. 185 µl for one well of a 96-well plate and pre-incubate/equilibrate plates in a humidified 37°C/5 % CO_2 incubator

2.5 Pre-warm an aliquot of culture media to 37°C (40 µl per sample see comments at the end of this chapter**)

2.6 Prepare 0.2–1 µg plasmid DNA or 0.4 µg pmaxGFP™ vector. For siRNA experiments we recommend to start using 30 nM–300 nM(0.6–6 pmol/sample)

2.7 Harvest the cells by trypsinization (please see 1.6–1.8)

2.8 Count an aliquot of the trypsinized cells and determine cell density

2.9 Centrifuge the required numbers of cells (4×10^5 cells per sample) at 90×g for 10 minutes at room temperature

2.10 Resuspend the cell pellet carefully in 20 µl room temperature HT Nucleofector™ solution per sample

A: One or several substrates (DNAs or RNAs) in multiples

- Prepare mastermixes by dividing cell suspension according to number of substrates
- Add required amount of substrates to each aliquot (max. 2 µl per sample)
- Transfer 20 µl of mastermixes into the wells of the 384-well Nucleocuvette™ plates

B: Multiple substrates (e.g. library transfection)

- Pipette 20 µl of cell suspension into each well of a sterile U-bottom 384-well microtiter plate
- Add 2 µl substrates (maximum) to each well
- Transfer 20 µl of cells with substrates into the wells of the 384-well Nucleocuvette™ plates

Note

It is advisable to pre-dispense each cell suspension into a sterile round-bottom 384-well plate or to pipet from a pipetting reservoir for multi-channel pipettes. Use a liquid handling system or at least a multi-channel pipette with suitable pipette tips. As leaving cells in HT Nucleofector™ solution for extended periods of time may lead to reduced transfection efficiency and viability it is important to work as quickly as possible. Avoid air bubbles while pipetting.

2.11 Briefly shake the 384-well Nucleocuvette™ plate with an appropriate microtiter plate shaker to make sure the sample covers the bottom and the sides of the wells without airbubbles. Alternatively thoroughly tap the 384-well Nucleocuvette™ plate

2.12 Place 384-well Nucleocuvette™ plate with closed lid onto the carousel of the plate handler of the HT Nucleofector™. Well "A1" must be in upper left position

2.13 Start Nucleofection™ process clicking "Start" in the HT Nucleofector™ software (for details refer to the HT Nucleofector™ manuals)

2.14 After run completion, carefully remove the 384-well Nucleocuvette™ plate from the carousel

2.15 Resuspend cells with desired volume of pre-warmed culture medium (maximum cuvette volume 60 µl). Mix cells by gently pipetting up and down two to three times. Recommendation for 384-well plates: Resuspend cells in 40 µl of pre-warmed media*

2.16 Plate desired amount of cells in culture system of your choice. Recommendation for 96-well plates: Transfer 15 µl of resuspended cells to 185 µl pre-warmed media

*** Note**

The indicated cell numbers and volumes have been found to produce optimal Nucleofection™ results in most cases, however, depending on your specific needs you may wish to test an extended range of cell numbers. Cell numbers and volumes can be adapted such that fewer cells are transferred or duplicate plates can be seeded.

3. Post Nucleofection™

3.1 Incubate the cells in a humidified 37°C/5 % CO_2 incubator until analysis. Gene expression is often detectable after only 4–8 hours

Additional information

Up-to-date List of all Nucleofector™ references

www.lonza.com/nucleofection-citations

Technical assistance and scientific support

USA/Canada
Tel 800 521 0390 (toll-free)
Fax 301 845 8338
scientific.support@lonza.com

Europe and Rest of World
Tel +49 221 99199 400
Fax +49 221 99199 499
scientific.support.eu@lonza.com

www.lonza.com

Lonza Cologne GmbH–50829 Cologne, Germany